

SRX LP

LANDFILL PUMP

“Simply”
Reliable



SRX LP Landfill Pump



The SRX LP Pump was removed from the well for inspection and cleaning after five months of trouble free operation.

SRX LP Landfill Pump

Minimal build-up has occurred around the air valve and pump linkage. This is attributed to the positive air valve seal



SRX LP Landfill Pump

Minimal build-up occurred on the center discharge tube. This is primarily due to the polished OD of the discharge tube and the movement of the hard surface Ebonite Float



SRX LP Landfill Pump



Build-up on the float OD and at the bottom of the arch assembly. The hard/slick surface of the float allowed the build-up to be wiped away with a light solvent and shop cloths



SRX LP Landfill Pump



The Pump was completely disassembled - cleaned and reassembled in the field. Since the float and control rod are easily removed cleaning was accomplished by wiping the pump with shop cloths and a light solvent in less then 30 minutes

SRX LP

SIMPLY RELIABLE

Any questions?